

LIFE MiniMix



Φραπεδιέρα χειρός, 25W

- Κατάλληλη για την προετοιμασία φραπέ, νες καφέ, αυγολέμονου, λαδολέμονου, κοκτέιλ, χυμών, παιδικών κρεμών, κ.α.
- Μεταλλικός άξονας 15cm για άνετη χρήση ακόμα και σε ψηλά ποτήρια
- Εργονομική λαβή
- Πρακτικός διακόπτης λειτουργίας
- Προστατευτικό καπάκι με ενδείξεις μετρήσεως (80ml)
- Τροφοδοσία: 220-240V~, 50/60Hz
- Ισχύς: 25W
- 2χρόνια εγγύηση

ΟΔΗΓΙΕΣ ΑΣΦΑΛΕΙΑΣ

1. Αποσυνδέετε πάντα τη συσκευή από την πρίζα μετά τη χρήση.
2. Μη βυθίζετε τη συσκευή μέσα σε νερό ή άλλο υγρό.
3. Έχετε πάντοτε υπό επιτήρηση τα παιδιά όταν χρησιμοποιούν τη συσκευή.
4. Αποσυνδέστε τη συσκευή από την πρίζα πριν την καθαρίσετε.
5. Κρατήστε το καλώδιο μακριά από ζεστές επιφάνειες ή πηγές θερμότητας.
6. Μη χρησιμοποιείτε τη συσκευή αν έχει φθαρεί το καλώδιο, το φις ή έχει υποστεί ζημιά.
7. Χρησιμοποιείτε τη συσκευή μόνο για τους σκοπούς που σχεδιάστηκε και κατασκευάστηκε.
8. Το προϊόν προορίζεται μόνο για οικιακή χρήση.

ΚΑΘΑΡΙΣΜΟΣ

Μην ξεπλένετε το mixer κάτω από τρεχούμενο νερό βρύσης. Τοποθετήστε τον άξονα μέσα σε ένα ποτήρι με καθαρό νερό και σκουπίστε με ένα καθαρό πανί.



Mini drink mixer, 25W

- Suitable for preparing Nescafe, Frappe, food sauces, juices, cocktails, baby creams, etc
- 15cm metallic shaft for comfortable use even with tall glasses
- Ergonomic handle
- Practical operation switch
- Protective shat cover/dozer (80ml)
- Input voltage: 220-240V~, 50/60Hz
- Power: 25W
- 2 years warranty

SAFETY INSTRUCTIONS

1. Disconnect it from the mains supply socket when not in use.
2. Do not immerse the motor unit in water or other liquid.
3. Keep always children under supervision when using the device.
4. Disconnect the mains supply socket before cleaning. Never leave the device unattended during operation.
5. Keep the power cable away from hot surfaces.
6. If the cord/plug becomes damaged or the appliance malfunctions, do not use the device.
7. Use the device only for the purpose it is designed for.
8. For domestic use only.

CLEANING

Do not wash the mixer under running tap water, instead run the axis in a cup of water and wipe it clean with a dry cloth.